

ALPHABETICAL INDEX

DESCRIPTION	GROUP NO.	DESCRIPTION	GROUP NO.
W - Cont.		W - Cont.	
WIRE, Alternator To Voltage Regulator.....	3.005	WIRE, Horn To Horn.....	3.192
WIRE, Ammeter To Ignition Switch.....	3.600	WIRE, Horn To Relay.....	3.192
WIRE, Ammeter To Starter Solenoid.....	3.600	WIRE, Ignition Coil To Junction Block.....	3.056
WIRE, Ammeter To Voltage Regulator.....	3.600	WIRE, Ignition Coil To Voltage Regulator...	3.056
WIRE, Automatic Transmission Kickdown Switch To Solenoid.....	16.245	WIRE, Ignition Switch To Blower Switch....	3.130
WIRE, Automatic Transmission Solenoid Connector To Kickdown Switch.....	16.245	WIRE, Ignition Switch To Circuit Breaker..	3.130
WIRE, Automatic Transmission Solenoid Kickdown Switch Jumper.....	16.245	WIRE, Ignition Switch To Circuit Breaker...	28.057
WIRE, Automatic Transmission Solenoid Kickdown Switch To Chassis Wiring Harness.....	16.245	WIRE, Ignition Switch To Flasher.....	3.130
WIRE, Automatic Transmission Solenoid Kickdown Switch To Junction Block....	16.245	WIRE, Ignition Switch To Neutral Safety Switch.....	3.130
WIRE, Back-Up Lamp.....	3.318	WIRE, Ignition Switch To Starting Motor....	3.130
WIRE, Back-Up Lamp Extension.....	3.318	WIRE, Ignition Switch To Voltage Regulator..	3.130
WIRE, Back-Up Lamp Switch To Body Wire Harness.....	3.318	WIRE, Ignition Switch To Windshield Wiper Switch Circuit Breaker.....	3.130
WIRE, Back-Up Lamp Switch To Circuit Breaker.....	3.318	WIRE, Instrument Cluster Voltage Regulator To Temperature Gauge To Gasoline Gauge	3.635
WIRE, Back-Up Lamp Switch To Connector..	3.318	WIRE, Junction Block To Ignition Switch....	3.213
WIRE, Back-Up Lamp Switch To Junction Block.....	3.318	WIRE, License Plate.....	3.341
WIRE, Back-Up Lamp To Body Wire Harness	3.318	WIRE, License Plate Lamp.....	3.341
WIRE, Back-Up Lamp To Connector.....	3.318	WIRE, Neutral Safety Switch Ground.....	3.022
WIRE, Back-Up Lamp Wire Harness Extension.....	3.318	WIRE, Neutral Safety Switch To Ignition Switch.....	3.022
WIRE, Blower Motor Ground.....	13.072	WIRE, Neutral Safety Switch To Junction Block.....	3.022
WIRE, Body Wire Harness To Gasoline Gauge	3.163	WIRE, Overdrive Indicator Light.....	6.380
WIRE, Center Domelamp.....	3.163	WIRE, Overdrive Kickdown Relay To Junction Block.....	6.365
WIRE, Cigar Lighter Assembly.....	3.352	WIRE, Overdrive Kickdown Switch.....	6.366
WIRE, Cigar Lighter To Ignition Switch....	3.352	WIRE, Overdrive Kickdown Switch.....	6.367
WIRE, Circuit Breaker To Back-Up Lamp Switch.....	3.154	WIRE, Overdrive Relay To Junction Block...	3.210
WIRE, Circuit Breaker To Top Switch.....	28.057	WIRE, Overdrive Solenoid Extension.....	6.328
WIRE, Clock.....	3.378	WIRE, Overdrive Wire Harness To Governor..	3.210
WIRE, Clock Feed.....	3.378	WIRE, Parking And Front Directional Signal Lamp.....	3.292
WIRE, Control Switch To Blower Motor.....	13.072	WIRE, Parking Brake Warning Lamp Switch To Circuit Breaker.....	3.650
WIRE, Courtesy Lamp Assembly.....	3.349	WIRE, Parking Brake Warning Lamp Switch To Fuse Panel.....	3.650
WIRE, Distributor To Coil High Tension....	3.232	WIRE, Parking Brake Warning Lamp To Switch.....	3.650
WIRE, Distributor To Coil Low Tension....	3.235	WIRE, Radio Capacitor.....	15.320
WIRE, Distributor To Ignition.....	3.232	WIRE, Radio Capacitor Jumper.....	15.320
WIRE, E-Stick Actuator Cam Switch Ground..	5.330	WIRE, Rear Domelamp.....	3.163
WIRE, Folding Top Operating Control Switch Extension.....	28.054	WIRE, Rear Seat Upholstery.....	29.114
WIRE, Front Domelamp.....	3.163	WIRE, Rectifier To Ground.....	3.005
WIRE, Front Seat Adjusting Slide Latch....	29.133	WIRE, Rectifier To Voltage Regulator.....	3.005
WIRE, Front Seat Upholstery.....	29.113	WIRE, Relay To Extension Wire.....	3.192
WIRE, Gasoline Gauge Extension.....	3.615	WIRE, Relay To Neutral Safety Switch.....	3.022
WIRE, Gasoline Gauge To Body Wire Harness	3.615	WIRE SET, Ignition.....	3.228
WIRE, Gear Selector Dial Light.....	7.535	WIRE, Tailgate Electric Window Regulator..	23.320
WIRE, Generator To Voltage Regulator.....	3.005	WIRE, Tail, Stop And Rear Directional Signal Lamp.....	3.312
WIRE, Glove Box Lamp.....	3.378	WIRE, Temperature Gauge Resistor.....	3.610
WIRE, Headlamp.....	3.288	WIRE, Temperature Sending Unit Extension..	3.165
WIRE, Headlining Listing.....	27.026	WIRE, Trunk Lamp Assembly Extension....	3.660
WIRE, Horn Contact.....	3.192	WIRE, Voltage Regulator "A" Terminal To Armature Terminal.....	3.012
WIRE, Horn To Chassis Wire Harness.....	3.192	WIRE, Voltage Regulator To Alternator.....	3.012
WIRE, Horn Ground.....	3.192		

***** Refer separate Upholstery parts catalog