



PLATE 5068

STARTING MOTOR 64 01-10 (SIX-196): 65 01 (LHE)(OHV-196)

KEY NO.	DELCO-REMY NUMBER	A.M. GROUP	A.M. PART NUMBER	DESCRIPTION	DELCO-REMY NO.	QUAN. REQ.
1	1928966	3.020	311 9543	END, Commutator		1
2	1906945			BRUSH		4
2		3.020	320 2006	BRUSH SET (Incl. 4 Brushes)		1
3	1926617	3.020	320 6082	HOLDER, Brush (Ground)		2
4	1926618	3.020	320 6083	HOLDER, Brush (Insulator)		2
5	1926622	3.020	311 9545	SPRING, Brush		2
6	1928015	3.020	320 6084	SUPPORT, Brush (Package) Holder		2
7	1926605	3.020	320 6085	#LEAD, Brush Ground		2
8	1933761	3.020	320 0936	COIL, Field (Incl. 4 Coils)		1
9				COIL, Shunt (Part of Key No. 8)		1
10	1955937	3.020	320 5019	ARMATURE		1
11				SPRING, Shift Lower Assist (Not Used)		1
12	1954842	3.020	320 5021	DRIVE ASSEMBLY		1
13	1927849	3.020	320 6087	COLLAR, Drive End Pinion Stop		1
14	1927848	3.020	320 6088	RING, Drive End Pinion Stop Retainer		1
15	1927850	3.020	320 6092	COLLAR, Drive End Thrust		1
16	1955193	3.020	320 5020	HEAD, Drive End (Drive Housing)(Incl. all parts coded with a *)		1
17	1114356	3.020	320 5022	SWITCH, Solenoid (Service Replacement For Delco-Remy #1114334)		1
18	1951792	3.020	320 6284	SPRING, Plunger Return (Use 320 6285)		1
19	1953041	3.020	320 4021	PLUNGER		1
20	1932205	3.020	320 6094	LEVER, Shift		1
21	455106	17.472	G455106	PIN, Plunger Attaching To Shift Lever (Not Available)		1
22	1932197	3.020	320 6098	STUD, Shift Lever		1
23	453296	17.820	G453296	#LOCKWASHER, Support Attaching Screw (Not Available)		4
24	274545	17.820	G274545	LOCKWASHER, Field Load Attaching Screw To Switch (Not Available)		1
26	120214	17.820	G120214	LOCKWASHER, Shift Level Stud (Not Available)		1
27	1869533	17.820	G9421423	LOCKWASHER, Switch Attaching (Not Available)		2