

KEY NO.	HOLLEY NO.	A.M. NO.	DESCRIPTION	PER CAR
59	36R-169	320 3189	@ φ * Float Retainer	1
60	36R-225	320 3190	@ φ * Air Vent Valve Retainer	1
61	38R-108	320 3191	X φ Fast Idle Cam Lever Screw Spring	1
62	38R-569	320 3196	@ W φ Diaphragm Return Spring	1
63	38R-110	320 3192	X φ Throttle Stop Screw Spring	1
64	38R-583	320 3197	X φ Fast Idle Cam Lever Spring	1
65	38R-931	320 3184	X φ Pump Lever Adjusting Spring	1
66	38R-760	320 3202	@ φ Air Vent Rod Spring	1
67	38R-803	320 3203	@ φ Float Spring (Blue)	1
68	39R-5	320 6344	▣ Choke Thermostat Shaft Hexagon Nut	1
69	39R-160	320 3206	@ φ Fuel Valve Seat Adjusting Nut	1
70	40R-108	320 3208	▣ φ Choke Thermostat Lever Spacer	1
71	41R-229A	320 6346	▣ Fast Idle Cam Assy.	1
72	41R-218	320 6348	Pump Cam	1
73	43R-203		∇ Choke Rod	1
74	43R-276		@ Air Vent Rod	1
75	46R-248	320 6349	▣ Choke Shaft Nut Shakeproof Lock Washer	1
76	47R-114A	320 3213	▣ Thermostat Housing Assy. (Cp.)	1
77	48R-31	320 3227	∇ φ * Choke Rod Retainer	2
78	49R-328		▣ Thermostat Housing Clamp	1
	49R-366		Dashpot Bracket (Not shown)	1
79	79R-425		@ Air Vent Rod Clamp	1
80	57R-35	320 6350	@ Filter Screen	1
	58R-50A	320 3188	Dashpot and Bracket Assembly (Not shown)	1
81	59R-34		@ Baffle Plate	1
82	63R-595		X Pump Operating Lever	1
83	75R-37	320 3240	X φ Pump Operating Lever Retainer	1

