

KEY NO.	HOLLEY NO.	A.M. NO.	DESCRIPTION	PER CAR
64	38R-583	320 3197	Zφ Fast Idle Cam Lever Spring	1
65	38R-931	320 3184	Zφ Pump Lever Adjusting Spring	1
66	38R-760	320 3202	@φ Air Vent Rod Spring	1
67	38R-803	320 3203	@φ Float Spring (Blue)	1
68	39R-5	320 6344	H Choke Thermostat Shaft Hexagon Nut	1
69	39R-160	320 3206	@φ Fuel Valve Seat Adjusting Nut	1
70	40R-108	320 3208	Hφ Choke Thermostat Lever Spacer	1
71	41R-229A	320 6346	H Fast Idle Cam Assy.	1
72	41R-218A	320 6348	Z Pump Cam (Red)	1
73	43R-203		∩ Choke Rod	1
74	43R-276		@ Air Vent Rod	1
75	46R-248	320 6349	H Choke Shaft Nut Shakeproof Lock Washer	1
76	47R-114A	320 3213	H Thermostat Housing Assy. (Cp.)	1
77	48R-31	320 3227	∩φ* Choke Rod Retainer	2
78	49R-328		H Thermostat Housing Clamp	1
79	49R-425		@ Air Vent Rod Clamp	1
80	57R-35	320 6350	@ Filter Screen	1
81	59R-34		@ Baffle Plate	1
82	63R-382		Z Pump Operating Lever	1
83	75R-37	320 3240	Zφ Pump Operating Lever Retainer	1