

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
<b>CAP, Oil Filler</b>				
60-61 01 (LHE): <b>62-63 01 (RHD)</b> ...(Incl. Gauge) .....		1	312 1952	
60-61 01-10 (OHVC) ...(Incl. Gauge) .....		1	315 5533	
62 01 (LHD-LHE) ...(Incl. Gauge) .....		1	316 3391	
62 01-10 (OHVC-LPB) ...(Incl. Gauge) .....		1	316 5891	
62 01-10 (LHD-OHVC-WPB) ...(Incl. Gauge) .....		1	316 5890	
63 01 (LHD-LHE) ...(Incl. Gauge) .....		1	316 7838	
63 01-10 (LHD-OHVC-WPB-Note 1.022-1) ...(Incl. Gauge) .....		1	316 6751	
63 01 (OHV-LDT-WPB-Note 1.022-2) .....		1	316 9355	
63 01-10 (OHVC-LPB-Note 1.022-1) ...(Incl. Gauge) .....		1	316 6752	
63 01 (OHV-LDT-LPB-Note 1.022-2) ...(Incl. Gauge) .....		1	316 9356	
61 Thru 63 10 (OHVA): 60 Thru 63 10-20-80 (V8) ... (Less Gauge) .....		1	314 4546	
64-65 01 (LHE) ...(Incl. Gauge) .....		1	317 2624	
64-65 01 (OHVC-196-LDT) .....		1	317 2043	
64-65 01 (OHVC-196-WDT): 64 10 (OHVC-196-Note 1.022-4) ... (Incl. Gauge) .....		1	317 1088	
64 10 (OHVC-196-WPB-Note 1.022-3) ... (Incl. Gauge) .....		1	317 1998	
64 10 (OHVC-196-LPB-Note 1.022-3) ... (Incl. Gauge) .....		1	317 2635	
65 01-80 (OHV-232-LFFC-Note 1.068-1 Type 1): 64-65 10 (OHV-232-LFFC-Note 1.068-1 Type 1) .....		1	317 4645	
65 01-10-80 (OHV-232-LFFC-Note 1.068-1 Type 2) .....		1	317 9998	
65 01-10-80 (OHV-232-WFFC-Note 1.068-1 Type 1): 65 01-10 (OHV-199-Note 1.068-1 Type 1): 64 10 (OHV-232-WFFC) .....		1	317 7626	
65 01-10-80 (OHV-232-WFFC-Note 1.068-1 Type 2): 65 01-10 (OHV-199-Note 1.068-1 Type 2): 64 10 (OHVA): 65 10-80 (V8-LSFC) .....		1	317 2621	
64 10 (OHV-232-WFFC) .....		1	317 7025	
64 10 (V8-287-LSFC) ... (Less Gauge) .....		1	317 2620	
64 10 (V8-327-LSFC): 64 80 (LSFC) ... (Less Gauge) .....		1	317 2619	
64-65 10-80 (V8-WSFC) ... (Less Gauge) .....		1	317 4215	

**SEAL, Oil Filler Pipe**

60 Thru 65 01 (OHVC-196): 60 Thru 64 10 (OHVC) .....		1	313 6326	
--	--	---	----------	--

**1.023 BEARING SET, Main**

(Std.) 60 Thru 65 01 (LHE)(OHV-196): 60 Thru 64 10 (OHVC-196) .....		1	320 4414	
(Std.) 65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....		1	320 5098	
(Std.) 61 Thru 64 10 (OHVA) .....		1	320 2666	
(Std.) 60 Thru 65 10-20-80 (V8) .....		1	311 9149	
(-.001) 60 Thru 65 01 (LHE)(OHV-196): 60 Thru 64 10 (OHVC-196) .....		1	320 4415	#
(-.001) 65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....		1	320 5099	
(-.001) 61 Thru 64 10 (OHVA) .....		1	320 2667	
(-.001) 60 Thru 65 10-20-80 (V8) .....		1	311 9620	
(-.002) 60 Thru 65 01 (LHE)(OHV-196): 60 Thru 64 10 (OHVC-196) .....		1	320 4416	
(-.002) 65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....		1	320 5100	
(-.002) 61 Thru 64 10 (OHVA) .....		1	320 2668	
(-.002) 60 Thru 65 10-20-80 (V8) .....		1	311 9621	
(-.010) 60 Thru 65 01 (LHE)(OHV-196): 60 Thru 64 10 (OHVC-196) .....		1	320 4417	
(-.010) 65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....		1	320 5101	
(-.010) 61 Thru 64 10 (OHVA) .....		1	320 2669	
(-.010) 60 Thru 65 10-20-80 (V8) .....		1	311 9622	
(-.012) 60 Thru 62 01: 60 Thru 62 10 (OHVC)(Replaces 320 3785)(Use 320 4418)		1	311 3186	
(-.012) 63 Thru 65 01 (LHE)(OHVC-196): 63-64 10 (OHVC-196) .....		1	320 4418	
(-.012) 65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....		1	320 5102	
(-.012) 61 Thru 64 10 (OHVA) .....		1	320 2670	
(-.012) 60 Thru 65 10-20-80 (V8) .....		1	311 9623	