

GROUP NO. — DESCRIPTION — YEAR and MODEL      PRIMARY GROUP NO.      PER CAR      PART NO.      CODE

**1. 101    BLOCK, Valve Rocker Arm Shaft**

60 Thru 62 01-10 (OHVC) .....	.....	6	314 4668	
63 Thru 65 01 (OHVC-196): 63-64 10 (OHV-196) .....	.....	6	316 6800	
61-62 10 (OHVA) .....	.....	6	316 0095	
60 Thru 65 10-20-80 (V8) .....	.....	8	314 9908	

**ATTACHING PARTS**

**Block To Shaft And Cylinder Head**

SCREW, Machine..... 60 Thru 65 01 (OHV-196): 60 Thru 64 10 (OHV-196) .....	.....	6	316 6905	
WASHER, Plain..... 60 Thru 65 01 (OHVC-196): 60 Thru 64 10 (OHV-196) .....	.....	2	400 1161	

**DOWEL, Valve Rocker Arm Shaft To Cylinder Head**

60 Thru 65 10-20-80 (V8) .....	.....	4	314 9568	
--------------------------------	-------	---	----------	--

**1. 102    DEFLECTOR, Valve Rocker Arm Shaft Oil**

65 01-80 (OHVC-232-#1 Cyl.): 64-65 10 (OHV-232-#1 Cyl.): 65 01-10 (OHV-199-#1 Cyl.) .....	.....	1	317 3392	
---	-------	---	----------	--

**RETAINER, Valve Rocker Arm Shaft**

65 01-80 (OHV-232): 64-65 10 (OHV-232): 65 01-10 (OHV-199) .....	.....	6	317 2310	
--	-------	---	----------	--

**1. 103    SCREW, Valve Rocker Arm Adjusting**

60 Thru 65 01 (OHVC-196): 60 Thru 64 10 (OHVC-196) .....	.....	12	314 4770	
60-61 20 .....	.....	16	315 1454	

**1. 105    TUBE, Valve Rocker Arm Oil**

60 Thru 64 01-10 (OHVC-196-Note 1. 105-1) .....	.....	1	314 7715	
64 01-10 (OHVC-196-Note 1. 105-2): 65 01 (OHVC-196) .....	.....	1	317 3642	

**ELBOW, Valve Rocker Arm Oil Tube**

60 Thru 63 01-10 (OHVC-196-1 Req. -At Oil Channel-Note 1. 105-2): 64-65 01 (OHVC-196-2 Req.): 64 10 (OHVC-2 Req.) .....	17. 218	1	G137420	
60-61 01-10 (OHVC-Less Oil Filter-At Cylinder Head) .....	.....	1	G137420	

**1. 108    COVER, Valve Tappet**

60 Thru 62 80 (LPV) .....	.....	1	316 3147	
61-62 20-80 (WPV): 63 10-80 (V8) .....	.....	1	320 3081	
64-65 10-80 (V8) .....	.....	1	320 5056	
(Front) 60 Thru 62 01 (LHD-LES-LPV): 60 10 (LHD): 61-62 10 (LHD-OHVC-LPV) .....	.....	1	314 7223	

- NOTE 1. 105-1:** On 64 01-10 (OHVC-196) used prior to Engine Code No. 508C05.  
**NOTE 1. 105-2:** On 64 01-10 (OHVC-196) used beginning with Engine Code No. 508C05.  
**NOTE 1. 108-1:** On 65 01 (LHE) used prior to Engine Code No. 610A06 and beginning with 610A07 and prior to 611A12; on 65 01 (LHE-Can) used prior to Engine Code No. 609A30. On 65 01 (OHV-196-WDT) used prior to Engine Code No. 611C04.  
**NOTE 1. 108-2:** On 65 01 (LHE) used beginning with Engine Code No. 610A06 and prior to 610A07 and beginning with 611A12; on 65 01 (LHE-Can) used beginning with Engine Code No. 609A30. On 65 01 (OHV-196-WDT) used with Engine Code No. 611C04.