

ELECTRICAL - INSTRUMENTS

3. 030

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
ROD, Neutral Safety Switch				
60 01 (WAT)	1	315 4776	
ATTACHING PARTS				
Rod To Lever				
PIN, Cotter	60 01 (WAT)	17.460	1	G103361 NA
WASHER, Plain	60 01 (WAT)	17.814	1	G120391 NA
TRUNNION, Neutral Safety Switch				
60 01 (WAT)	1	314 3995	
ATTACHING PARTS				
Trunnion To Rod				
NUT, Hexagon	60 01 (WAT)	17.412	2	G142212 NA
WASHER, Plain	60 01 (WAT)	17.814	1	G446188 NA
WIRE, Neutral Safety Switch To Junction Block				
60 10-20-80 (WAT)	1	315 7924	
61 10-20-80 (WAT-Note 3.022-1 Type 1)	1	316 1345	
ATTACHING PARTS				
Wire To Heater Hose				
CLIP	61 10 (LHD-WAT)	8.192	1	313 0165
Wire To Wire Harness				
CLIP	61 10-20-80 (WAT-Note 3.022-1 Type 1)	3.210	2	63 045
WIRE, Neutral Safety Switch To Ignition Switch				
64-65 01 (LHD-WAT): 64-65 10-80 (WAT-WCGS-WAW)	1	317 1137	
COVER, Starting Motor Neutral Safety Switch				
62 10-80 (WAT)	1	316 5840	
3.030 DISTRIBUTOR (For Components Refer To Group 3 Charts)				
(Auto-Lite IAT-4402-1) 60-61 01 (LHE)	1	315 7209	
(Auto-Lite IAT-4407) 62 01 (LHE)	1	316 4149	
(Auto-Lite IAT-4408): 162 10 (CAN)	1	316 5688	
(Auto-Lite IAT-4414): 163 10 (CAN) (For Components Refer To CAN. Chart CH 3-9)	1	316 9407	
(Auto-Lite IAT-4414A): 165 01 (OHV-CAN); 164 10 (OHV-196-CAN)	1	317 3162	
(Auto-Lite IAT-4415): 163 01 (CAN-LHE) (For Components Refer To CAN. Chart CH 3-7)	1	316 9406	
(Auto-Lite IAT-4415A): 164-165 01 (CAN-LHE)	1	317 3161	
(Auto-Lite IBP-4104), 60 80	1	315 7223	
(Auto-Lite IBP-4104A) 60 20	1	315 7218	

NOTE 3.030-1: For Components refer to page CH 3-75. All parts identical except, when ordering Key No. 32. Order IAT-100 in place of GAR-98A. Lower Thrust Washer, IG-313 (Not Illustrated) is included on CAN distributor.