

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
Switch To Bracket				
SCREW, Tapping..... 63 10-80	13.017	2	400 0616	
BEZEL, Ignition Switch				
64-65 01		1	350 0727	
65 10 (550)(Except Marlin).....		1	351 6735	
65 10 (660)(770): 65 80		1	351 6736	
ATTACHING PARTS				
Bezel To Lower Instrument Panel				
NUT, Speed..... 65 10 (550-2 Reg.)(660-3 Req.)(770-3 Req.)	22.060	AR	400 1352	
NUT, Speed..... 65 80.....	22.060	3	400 1352	
ESCUTCHEON, Starter And Ignition Switch				
65 10 (LHD)		1	351 6585	
65 50 (Marlin): 65 80		1	353 0329	
BRACKET, Ignition Switch To Instrument Panel				
63-64 10-80: 65 10 (RHD).....		1	348 2641	
ATTACHING PARTS				
Bracket To Instrument Panel				
SCREW, Tapping..... 63 10-80.....	17.660	2	G161869 NA	
CLIP, Solenoid And Relay Harness To Chassis Harness				
63 10 (WES)	3.210	5	63 045	
CLIP, Solenoid And Neutral Start Harness To Wheelhouse				
63 10 (WFGS).....	3.210	3	312 3849	
WIRE, Ignition Switch To Flasher (Shielded)				
60-61 10-20-80 (Heavy Duty)(Taxicabs And Police Cars) ... (Replaces 342 3076)		1	345 5671	
64-65 01 (Heavy Duty)(Taxicabs And Police): 63 10-80 (Heavy Duty)(Taxicabs And Police): 65 10-80 (Heavy Duty)(Taxicabs And Police)		3	316 9541	
WIRE, Ignition Switch To Blower Switch (Incl. Fuse Holder)				
60 01 (OAC)		1	320 1989	
60 10 (WAE-Note 3.005-7)	3.130	1	316 1435	
WIRE, Ignition Switch To Starting Motor				
62 01-10 (WAE-Note 3.005-8).....	3.206	1	314 3933	
62 80 (WAE-Note 3.005-8)		1	316 4906	
WIRE, Ignition Switch To Voltage Regulator				
62 01-10 (WAE-Note 3.005-8)		1	316 4910	
HARNESS, Ignition Switch To Flasher (Shielded)(3 Wire)				
62-63 01 (Heavy Duty)(Taxicabs And Police Cars): 60 Thru 62 10-20-80 (Heavy Duty)(Taxicabs And Police Cars).....		1	345 5671	