

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
FUSE, Headlamp Switch				
62-63 01: 62 10-80.....	17.300	1	G455640	
BRACKET, Courtesy Lamp Switch To Instrument Panel				
61 Thru 63 01 (Note 3.349-1 Type 1).....	3.349	1	346 0651	
ATTACHING PARTS				
Courtesy Lamp Switch Bracket To Instrument Panel				
SCREW, Tapping..... 63 01 (Note 3.349-1 Type 1).....	17.660	2	G161901	NA
NUT, Spring..... 63 01 (Note 3.349-1 Type 1).....	17.422	2	G455138	NA
BRACKET, Headlamp Switch To Instrument Panel				
63-64 10-80: 65 10 (RHD)	1	348 2827	
ATTACHING PARTS				
Headlamp Switch Bracket To Instrument Panel				
SCREW, Tapping..... 63 10-80.....	13.017	2	400 0616	
RESISTOR, Headlamp Switch Rheostat				
60 01.....	1	320 2456	
60 10-20-80.....	1	320 2455	
RHEOSTAT, Headlamp Switch				
61 Thru 63 01: 61-62 10-20-80.....	1	320 3011	
64-65 01: 63 Thru 65 10-80.....	1	320 4440	
3.150 KNOB, Lighting Switch				
60 01.....	1	343 2301	
61 01 (Gray).....	1	346 0252	
61 Thru 63 01 (Black).....	1	341 6978	
64-65 01.....	1	350 9449	
60 Thru 62 10-20-80.....	1	344 0595	
63 10-80.....	1	348 2941	
64 10-80: 65 10 (RHD)	1	350 9548	
65 10 (LHD)(Except Marlin).....	1	351 6592	
65 50 (Marlin): 65 80.....	1	351 6591	
3.154 BREAKER, Circuit				
(15 AMP) 60 Thru 65 10-20-80.....	23.325	1	344 1432	
(20 AMP) 62-63 01: 62 10-80.....	1	316 5820	
(20 AMP) 65 10-80.....	23.325	1	353 0349	
(25 AMP) 63 Thru 65 18-88: 64-65 08.....	23.325	1	349 0464	
(30 AMP) 60 Thru 63 01: 60 Thru 62 10-20-80: 63 10-80 (WER).....	1	439 0679	
(30 AMP) 64 01-10-80: 65 07 (WPT): 65 10-80.....	23.325	1	317 1130	
PLATE, Circuit Breaker Mounting				
61 Thru 63 01: 60 Thru 62 10-20-80.....	1	344 4036	