

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
4.110 PUMP, Fuel				
(AC-5621658) 60 01		1	315 5483	
(Carter MDOF-3184S) 61 01 (LHD)..... (Use 316 3647)		1	316 1249	#
(Carter M-774-SA) 61 Thru 63 01 (RHD)		1	313 0091	
(Carter MDOF-3344S) (Use For Carter MDOF-3184SA) 62 01 (LHD)		1	316 3647	
.....(Replaces 316 4647)				
(Carter MPOF-3730S) 63 Thru 65 01 (LHD-LHE-WVW)		1	316 7610	
(Carter MOF-3723S) 64-65 01 (LHE-WEW)		1	317 2795	
(Carter MPF-3531) 63 Thru 65 01 (OHV-196-WVW): 63-64 10 (LHD-OHV-196-WVW)(OHVC-196-WES-WEW)		1	316 7730	
(Carter MPF-3011S) 60 10		1	315 8342	
(Carter MPF-3025SA)(Use For Carter MPF-3025S) 60-61 10: 62 10 (LHD)		1	316 4578	
.....(Replaces 315 8546)				
(Carter MPF-3346) 62 Thru 64 10 (RHD-OHV-196-WVW)		1	316 3880	
(Carter MF-3598S) 64 01 (OHV-WEW-LES): 63-64 10 (LES-WEW-OHV-196): 65 01 (OHV-196-WEW)		1	317 0521	
(Carter M-3763) 64 10 (OHV-232-WVW)(OHV-232-WES): 65 10 (OHV-232-WVW-LDT-Note 4.110-1)		1	317 3221	
(Carter M-3805) 65 01 (OHV-199-WEW)(OHV-232-WEW): 65 01 (RHD-OHV-199): 64 10 (OHV-232-WEW): 65 10-80 (Six-WEW)		1	317 3674	
(Carter MPF-2988S) 60 20-80		1	315 7894	
(Carter MPF-3158) 61 Thru 65 10-20-80 (V8-WVW)		1	316 0756	
(Carter MF-3599S) 63 Thru 65 10-80 (V8-WEW)		1	317 0522	
(Carter MPOF-3943) 65 01 (OHV-232-WVW)(OHV-199-WVW): 65 10-80 (Six-WVW-Note 4.110-2)		1	320 6148	
.....(Replaces 317 7277)				
ATTACHING PARTS				
Pump To Block				
BOLT, Hexagon	60 01-10 (OHV): 61-62 01: 61-62 10 (OHVC)	2	313 0125	
BOLT, Hexagon	60 01 (LHE)	17.038	2	G179822 NA
BOLT, Hexagon	63-64 01: 61-62 10 (OHVA): 63-64 10 (OHV-196) ...	2	316 0300	
BOLT, Hexagon	64 10 (OHV-232): 65 01-10 (Six)	17.038	2	G180081
WASHER, Lock	60 Thru 65 01-10 (Six)	17.820	2	G103320 NA
Pump To Front Cover				
BOLT, Hexagon	60 Thru 65 10-20-80 (V8)	17.038	2	G180126 NA
WASHER, Lock	60 Thru 65 10-20-80 (V8)	17.820	2	G120382 NA
BOWL, Fuel Pump Filter				
60 10-20-80		1	320 2350	
63 Thru 65 01 (LHD-LHE).....	4.002	1	311 7225	#
63 Thru 65 01 (OHV): 63 Thru 65 10-80		1	320 4193	
GASKET, Fuel Pump Filter Bowl				
63 Thru 65 01-10-80.....	4.002	1	311 7226	#
SPRING, Fuel Pump Filter Bowl				
63 Thru 65 01 (LHD-LHE).....		1	311 7228	
63 Thru 65 01 (OHV): 60 10-20-80: 63 Thru 65 10-80.....		1	320 2351	
ELEMENT, Fuel Pump				
61 01-10.....	15.190	1	899 0952	
62 Thru 64 01-10: 61 Thru 64 20-80 (Use With Glass Bowl).....	15.190	1	899 0953	
63 Thru 65 01-10-80 (Use With Metal Bowl).....	15.190	1	899 1450	

NOTE 4.110-1: On 65 10 (OHV-232-LDT-WVW) used prior to Engine Code No. 608L04.
 NOTE 4.110-2: On 65 10 (OHV-232-LDT-WVW) used beginning with Engine Code No. 608L04.